

The LCD quickly and accurately displays the current input pressure and the high and low pressure set points. If the high pressure set point is reached, the display will flash **High** and if the low pressure set point is reached the display will flash **Low**.

The **HIGH LIMIT** button allows the operator to set the high pressure set point. Press and hold the **HIGH LIMIT** button while pressing the **UP** or **DOWN** buttons until the desired pressure is displayed on the LCD.

The **LOW LIMIT** button allows the operator to set the low pressure set point. Press and hold the **LOW LIMIT** button while pressing the **UP** or **DOWN** buttons until the desired pressure is displayed on the LCD.

The **UP** and **DOWN** buttons are used to set the desired operation setpoints and clears the high and low limit counts.

Scroll through **DATA** button to read **High Count** (number of times the pressure switch has detected a HIGH setpoint), **Low Count** (number of times the pressure switch has detected a LOW setpoint), **Delay** (Time delay before the controller reacts to a setpoint), and **Battery Voltage**.

*Delay - Time delay before the controller reacts to a high or low setpoint. While holding the **DATA** button and reading delay on the LCD, use the **UP** and **DOWN** buttons to set the desired delay time.

